

USING CLASSROOM ‘SMART CARTS’ WITH A LAPTOP

The ‘Smart Cart’ podiums provide user-friendly connections to a laptop. They support Windows or Mac Laptops as well as a permanently installed workstation and VHS/DVD player. It also provides an amplifier and speakers for audio presentations and includes network cabling and electrical connections for easy fitting.

LAPTOP COMPUTER CONNECTION

All connections are labeled pictorially on the top of the smart cart.

1. Connect the video (15 pin plug), network (wide clear plug), sound and power cables to the laptop. Power is located on the back of the cabinet.
2. Turn the main cart power switch on. Power switch is located in the recessed panel.
3. Select the ‘laptop’ option by pressing the Laptop/CPUI button on the top panel. You should see a yellow LED light indicating laptop.
4. Power on the Projector. Use the remote control labeled Data Projector. As the projector warms up it will display which input is active. Look for RGB1 to be displayed. If not, press RGB on the remote until RGB1 is displayed.
5. Power on the Laptop.